



## Koro-Trans™

### Repair Suggestions for Koro-Trans™ Flooring Products

#### Flooring Seam Gaps

Oatey Medium PVC cement is recommended to fill small areas where damage has occurred to the flooring. The cement will bond the flooring to itself and is useful to fill gaps between flooring sections, or to repair areas where the floor has been mechanically damaged in service. If the flooring bond to the subfloor has been disturbed, a suitable contact cement should be used to bond it to the subfloor prior to gap filling or other flooring repair using the PVC cement. DAP Weldwood contact cement can be used for this purpose.

Oatey PVC cement is available in a grey color that matches KoroTrans Dark Gray flooring. It is also available in clear which can be used on any flooring color.

#### Process Suggestions:

- 1) Remove foreign material from repair area.
- 2) Wipe area with acetone (a clean rag is critical to avoid discoloring the flooring, replace rags often).
- 3) Trim bottle tip to suit gap width. 16 ounce squeezable Boston Round Bottles work well.
- 4) Place bottle tip in gap and continuously dispense a bead large enough to fill the gap and preferably flow onto the top edge of the flooring.
- 5) Let the cement dry for a couple of hours (longer is better).

If you get some excess cement onto the flooring, don't try to clean it, just let it dry and it will blend in with the flooring.

This work should be done with windows and doors open for maximum ventilation. The odor of the PVC cement will dissipate more or less quickly as a function of the amount of ventilation of the work area. This process is very forgiving. If a void occurs after the cement has dried just go back and put a little more cement down to fill the void.



**Koro-Trans Products  
ProFusion Industries  
822 Kumho Drive  
Fairlawn, OH 44333**

**800 938-2858**

**[www.profusionindustries.com](http://www.profusionindustries.com)**